


für Uhrwerke FK, FP, FW, GK, WL

Zeigerbuchse Minutenzeiger: Ø 3,5 mm, Stundenzeiger Ø 5,0 mm



40/30 mm

Zeiger Nr. 11



40/30 mm

Zeiger Nr. 12



40/29 mm

Zeiger Nr. 13



40/29 mm

Zeiger Nr. 14



45/34 mm

Zeiger Nr. 19



45/34 mm

Zeiger Nr. 20



48/36 mm

Zeiger Nr. 23



53/38 mm

Zeiger Nr. 25




55/40 mm

Zeiger Nr. 27



58/44 mm

Zeiger Nr. 28



58/44 mm

Zeiger Nr. 29



59/45 mm

Zeiger Nr. 30



59/38 mm

Zeiger Nr. 32



60/43 mm

Zeiger Nr. 34




60/43 mm

Zeiger Nr. 35



63/45 mm

Zeiger Nr. 36




63/45 mm

Zeiger Nr. 37




65/45 mm

Zeiger Nr. 38



65/54 mm

Zeiger Nr. 39




71/53 mm

Zeiger Nr. 41



72/51 mm

Zeiger Nr. 42



72/51 mm

Zeiger Nr. 43



72/49 mm

Zeiger Nr. 44



72/49 mm

Zeiger Nr. 45



76/51 mm

Zeiger Nr. 46



80/52 mm

Zeiger Nr. 49



82/56 mm

Zeiger Nr. 53



88/60 mm

Zeiger Nr. 61




88/60 mm

Zeiger Nr. 61




92/70 mm

Zeiger Nr. 64



92/70 mm

Zeiger Nr. 65



100/74 mm

Zeiger Nr. 70



103/72 mm

Zeiger Nr. 72



103/72 mm

Zeiger Nr. 73




120/90 mm

Zeiger Nr. 77



122/90 mm

Zeiger Nr. 82



140/100 mm

Zeiger Nr. 86

Zeigerbuchsen (Lochmaße)

Minutenzeiger: 3,5 mm

Stundenzeiger: 5 mm

Bei Anfragen bitte die Zeigernummer und die Lochmaße angeben.