



für Uhrwerke CK, CL, CP, CR, CX, EX, FD, FL, G, IK, MQ, WB, WD, WH, WK, WO, WX, WZ
Zeigerbuchse Minutenzeiger: 2,8 x 3,5 mm, Stundenzeiger Ø 5,0 mm




80/55 mm
Zeiger Nr. 52




80/52 mm
Zeiger Nr. 53



82/56 mm
Zeiger Nr. 54



85/65 mm
Zeiger Nr. 55



85/65 mm
Zeiger Nr. 56



87/73 mm
Zeiger Nr. 58




87/73 mm
Zeiger Nr. 59




88/66 mm
Zeiger Nr. 60



88/60 mm
Zeiger Nr. 61




88/60 mm
Zeiger Nr. 61




88/67 mm
Zeiger Nr. 62



90/65 mm
Zeiger Nr. 63



92/70 mm
Zeiger Nr. 64



92/70 mm
Zeiger Nr. 65




100/75 mm
Zeiger Nr. 67



100/75 mm
Zeiger Nr. 68



100/75 mm
Zeiger Nr. 69




100/74 mm
Zeiger Nr. 70




101/73 mm
Zeiger Nr. 71




103/72 mm
Zeiger Nr. 72



103/72 mm
Zeiger Nr. 73



110/79 mm
Zeiger Nr. 76




120/90 mm
Zeiger Nr. 77




120/85 mm
Zeiger Nr. 78



121/87 mm
Zeiger Nr. 80



121/87 mm
Zeiger Nr. 81




122/90 mm
Zeiger Nr. 82



125/96 mm
Zeiger Nr. 83



135/100 mm
Zeiger Nr. 84



135/100 mm
Zeiger Nr. 85




140/100 mm
Zeiger Nr. 86



160/100 mm
Zeiger Nr. 87



160/115 mm
Zeiger Nr. 88




180/140 mm
Zeiger Nr. 89



180/140 mm
Zeiger Nr. 90




200/155 mm
Zeiger Nr. 91



200/155 mm
Zeiger Nr. 92



220/170 mm
Zeiger Nr. 93



220/170 mm
Zeiger Nr. 94

Zeigerbuchsen (Lochmaße)

Minutenzeiger: 2.8 x 3.5 mm

Stundenzeiger: rund 5 mm

Bei Anfragen bitte die
Zeigernummer und die
Lochmaße angeben.